


GENERAL NOTES :

1. ADD ISOLATION VALVES AND UNIONS AS NEEDED.

KEYED NOTES :

- ① INSTALL KINGSPAN, HP-450 SOLAR COLLECTORS IN SERIES UP TO 6 UNITS. FOR MULTIPLE ROW SYSTEMS REFER TO SOLAR ARRAY FLOW DIAGRAM, DHW-10.
- ② SOLAR CONTROL AND PUMP STATION. CONNECT TO ALL RTD's: ((R)) SYMBOLS.
- ③ MIXING VALVE (SEE MIXING VALVE DETAIL DHW-0).
- ④ ROUTE T&P RELIEF VALVE (PRESSURE RELIEF ONLY FOR SOLAR STORAGE TANKS) DISCHARGE, FULL SIZE, TO FLOOR DRAIN.
- ⑤ PRESSURE REDUCING VALVE - INSTALL ONLY IF WATER SUPPLY PRESSURE EXCEEDS 75% OF WATER HEATING SYSTEM DESIGN PRESSURE.
- ⑥ ASME THERMAL EXPANSION TANK - SIZE ACCORDING TO MANUFACTURER'S RECOMMENDATION.
- ⑦ COMBINATION TEMPERATURE AND PRESSURE GAUGE - INSTALL WITHIN 12" OF HOT WATER OUTLET.
- ⑧ PROVIDE FULL-PORT DRAIN VALVE AND ROUTE TO FLOOR DRAIN.
- ⑨ RECIRCULATION PUMP. PROVIDE AQUASTAT ONLY IF REQUIRED BY CODE WITH LETTER TO OWNER REQUIRING RELEASE OF LIABILITY (NON-MOVING WATER PROMOTES LEGIONELLA).
- ⑩ ATTACH RTD SENSOR TO W/H TANK WALL.
- ⑪ INSTALL BATTERY OPERATED FREEZE PROTECTION VALVE, 3/4", STAINLESS VALVE BODY, WITH ACTUATOR TO OPEN TO FLOOR DRAIN WHEN COLLECTOR TEMPERATURE SENSOR DETECTS ABOUT 38 DEG. F AND SOLAR PUMP IS NOT ACTIVATED.



RAND ASSOCIATES INCORPORATED

Domestic Hot Water Flow Diagram
Dual Water Heater
Dual Water Heaters are Solar Storage

PIPING
DIAGRAM

Size: A	FSCM No: -	Drawing No: DHW-23	Version: 1
Drawn By: BLW	Scale: NONE	Date: 11.28.12	Sheet: 1 of 1